

## **uEye SE USB 3.1 Rev. 1.2**

### **Technical Manual**

**uEye+**



IDS Imaging Development Systems GmbH  
Dimbacher Str. 10  
D-74182 Obersulm, Germany  
T: +49 7134 96196-0  
E: [info@ids-imaging.com](mailto:info@ids-imaging.com)  
W: <https://en.ids-imaging.com>

## Imprint

This document was created by:

IDS Imaging Development Systems GmbH  
Dimbacher Str. 10  
D-74182 Obersulm, Germany, Germany  
[info@ids-imaging.com](mailto:info@ids-imaging.com)

Editorial deadline: June 2024

We reserve the right to modify this document for reasons of further development.

## Copyright

© IDS Imaging Development Systems GmbH. All rights reserved. This manual may not be reproduced, transmitted or translated to another language, either as a whole or in parts, without the prior written permission of IDS Imaging Development Systems GmbH.

## Trademarks



The IDS logo is a registered trademark of IDS Imaging Development Systems GmbH, registered for U.S. (Reg.No. 4,513,138) and other countries.

**IDS NXT** and **uEye** are registered trademarks of IDS Imaging Development Systems GmbH. Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation. USB Type-C<sup>®</sup> and USB-C<sup>®</sup> are registered trademarks of USB Implementers Forum. All other products or company names mentioned in this manual are used solely for purposes of identification or description and may be trademarks or registered trademarks of the respective owners.

## Contact us

[info@ids-imaging.com](mailto:info@ids-imaging.com)

<https://en.ids-imaging.com>

### Headquarters

IDS Imaging Development Systems GmbH  
Dimbacher Str. 10  
D-74182 Obersulm, Germany | Germany  
+49 7134 96196-0

### Subsidiaries

**UK:** IDS Imaging Development Systems Ltd.  
Cheyenne House, West Street  
GU9 7EQ Farnham | United Kingdom  
+44 1252 916656

**JP:** IDS Imaging Co., Ltd.  
3F, Mita Nexus Building, 1-3-33 Mita, Minato-ku  
108-0073 Tokyo | Japan  
+813 4500 8864

**US:** IDS Imaging Development Systems Inc.  
92 Montvale Ave, Suite 4750  
02180 Stoneham, MA | U.S.A  
+1 781 787-0048

**KR:** IDS Imaging Development Systems Korea Ltd.  
풍림아이원 A동 607호  
경기도 성남시 분당구 서현로 170 | South Korea  
+82 31-607-0104

## Contents

<b>1 Symbols and hints</b>	<b>5</b>
<b>2 Safety instructions</b>	<b>6</b>
<b>3 uEye SE USB 3.1 Rev. 1.2</b>	<b>9</b>
3.1 Standards and directives	9
3.1.1 Housing version	10
3.1.2 PCB version	11
3.2 Ambient conditions	11
3.3 System requirements	12
3.4 Connecting a uEye SE USB 3.1 Rev. 1.2	13
<b>4 Mechanical specifications</b>	<b>14</b>
<b>5 Notes on PCB version</b>	<b>15</b>
<b>6 Optical specifications</b>	<b>18</b>
6.1 Immersion depth for lenses	18
6.2 Position accuracy of the sensor	19
<b>7 Electrical specifications</b>	<b>20</b>
7.1 Pin assignment I/O connector	20
7.2 Digital input wiring	21
7.3 Digital output wiring	22
7.4 General Purpose I/O wiring	23
<b>8 Operating the uEye SE USB 3.1 Rev. 1.2</b>	<b>27</b>
8.1 Status LED	27
8.2 Filter types	28
<b>9 Maintenance</b>	<b>31</b>
9.1 Cleaning the filter glasses	31
9.2 Cleaning the sensor	32
<b>Index</b>	<b>33</b>

## 1 Symbols and hints

---



This symbol indicates hints with useful information for better understanding and using features and functions.

---



This symbol indicates important warnings for product safety to prevent damage.

---



This symbol indicates important warnings for personal safety to prevent injury.

---

## 2 Safety instructions

Read carefully these safety instructions before installing and using the product. The producer is not responsible for damages and injury, which can occur due to false handling of the product and ignoring the safety instructions. All warranty will be spoiled in this case.

### Intended use

IDS industrial cameras are to be used to capture images for visualization and image processing tasks. They are designed for use in industrial environments. Observe the requirements for the proper use of this product. Failure to do so will render the warranty void.

- The product is not authorized for use in security relevant applications. If it is used in security relevant applications, the customer is responsible for the necessary approvals.
- If the product is modified or changed, all approval becomes invalid. In this case, the customer is responsible for ensuring product conformity.
- The warranty expires if the product is improperly disassembled, reworked or repaired by the customer or a third party and IDS Imaging Development Systems GmbH assumes no liability for defects. If you need service, please contact the support team.
- The product is not a toy. Operate and store out of the reach of children.

### Protection against electrostatic discharge (ESD)

Board-level cameras are especially sensitive to electrostatic discharge. Make sure to avoid mechanical or electrical damage of the printed circuit board or its connections. Wear ESD-protective clothing and observe the rules for handling ESD-sensitive components.

- Do not touch the printed circuit board while it is powered.
- Always hold the board by the edges to avoid the risk of electrostatic discharge damage.
- For optimum ESD behavior, a clearance of 4 mm from non-shielded housings must be maintained all the way around. For shielded housings, a smaller clearance is possible.
- Attach the board to a conductive surface using the fixing screws. If this is not possible, ensure an insulating connection.
- Use connecting cable with a low-resistance shield on both sides.

### Installation, operation and maintenance

The product must be connected, taken into operation and maintained only by appropriately qualified personnel. The error-free and safe operation of this product can only be ensured if it is properly transported, stored, set up and assembled, and operated and maintained with due care. The installation, inspection, maintenance, extension, and repair may only be done by authorized personnel.

- Observe the specifications in the documentation when installing the product.

- Do not subject the product to direct sunlight, moisture or shock. Ensure that the IP code of the product meets the requirements for the ambient conditions.
- Only operate the product under ambient conditions for which the respective product is approved. The use under other ambient conditions may result in damage.
- To avoid any damage to the connectors, only mount or remove the product with the cables disconnected.
- Lay cables in such a way that no one is endangered.
- Before starting up, check if the electrical wiring corresponds to the specifications in the documentation. Faulty wiring (overvoltage, undervoltage) can result in a damage in the electronics.

### Transport

- Only use ESD packaging for storage and transport of ESD-sensitive components.
- Keep packing materials like films away from children. Abuse may result in suffocation.

### Operation and power supply

The camera power supply must meet the requirements for SELV (safety extra low voltage)/LPS (limited power source) or ES1/PS2.

**WARNING!** A USB hub with external power supply may cause painful or dangerous electric shock. Serious injury or death may occur. Use a USB hub that meet the requirements for SELV (safety extra low voltage)/LPS (limited power source) or ES1/PS2.

---

### Avis pour le Canada

#### Fonctionnement et alimentation électrique

*L'alimentation électrique de la caméra doit être conforme aux exigences de sécurité SELV (très basse tension de sécurité)/LPS (source à puissance limitée) ou ES1/PS2.*

**AVERTISSEMENT !** Sur un concentrateur USB équipé d'une alimentation externe, il existe des risques de décharges électriques douloureuses ou dangereuses. Celles-ci peuvent provoquer des blessures graves, voire mortelles. Utilisez un concentrateur USB conforme aux exigences de sécurité SELV (très basse tension de sécurité)/LPS (source à puissance limitée) ou ES1/PS2.

---

**CAUTION!** As the camera housing may get hot depending on the operating conditions there may be risk of burns. Provide sufficient heat dissipation so that the housing temperature does not exceed 55 °C (131 °F).

### Correct disposal

Dispose the camera and accessories properly and separately from other types of waste to encourage recycling of reusable materials and to protect the environment.

According to the EC Directive 2012/19/EU (WEEE) we are obliged to take back this product, distributed by us after August 13, 2005, free of charge at the end of its useful life and to ensure its correct disposal. As this product is exclusively for commercial use (B2B), it must not be handed over to a public disposal facility. The product can be disposed of by specifying the date of purchase and the serial number at the following address:

IDS Imaging Development Systems GmbH  
Dimbacher Str. 10  
D-74182 Obersulm, Germany



### 3 uEye SE USB 3.1 Rev. 1.2

Housing/board level	+/+
Dimensions height x width x length	Housing version: 34 x 44 x 47 mm PCB version: 29.5 x 40 x 25 mm PCB version with C-mount: 34 x 44 x 31 mm
Mechanical specifications	<a href="#">Mechanical specifications</a>
IP code housing version	<b>IP 30</b> <ul style="list-style-type: none"><li>• Protection against the ingress of small particles (diameter ≥ 2.5 mm)</li><li>• No protection against water</li></ul>
IP code PCB version	<b>IP 00</b> <ul style="list-style-type: none"><li>• No protection against the ingress of particles</li><li>• No protection against water</li></ul>
Ambient conditions	<a href="#">Ambient conditions</a>
Lens mount	C-mount, see <a href="#">Optical specifications</a>
Mounting holes bottom/top/side/front	Housing version: 4/0/0/0 PCB version: 2x back, see <a href="#">Notes on PCB version</a> PCB version with C-mount: 2/0/0/0
Thread diameter	M3
Status LED	<a href="#">Status LED</a>
Interface connector	USB Type-C®, screwable
Power supply	USB
I/O connector	<a href="#">8-pin Hirose HR25</a> , screwable
Electrical specifications	<a href="#">Electrical specifications</a>
Special features	Integrated image memory Internal pixel preprocessing



USB 3/USB 3.1 uEye+ cameras are limited usable under USB 2.0. Depending on the camera model, not all camera functions are available in USB 2.0 mode. USB 3/USB 3.1 uEye+ cameras are optimized for USB 3.0 ports and are not tested by IDS Imaging Development Systems GmbH under USB 2.0.

Please note that due to the high performance of modern sensors, some USB 3/USB 3.1 uEye+ models are not supported in USB 2.0 mode anymore, as the USB 2.0 interface does not provide enough power.

#### 3.1 Standards and directives

[Housing version](#)

[PCB version](#)

### 3.1.1 Housing version

IDS Imaging Development Systems GmbH hereby confirms that this product has been developed, designed and manufactured in compliance with the following European directives

- 2014/30/EU: EMC - Electromagnetic compatibility
- 2011/65/EU: RoHS - Restriction of the use of certain hazardous substances in electrical and electronic equipment
- Regulation (EC) No. 1907/2006 concerning the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH)
- The CE declaration of conformity is available on the [IDS website](#).

If the product is modified or changed all approval becomes invalid. In this case the customer is responsible for ensuring product conformity.

<b>Product type</b>	uEye SE USB 3.1 Rev. 1.2
<b>Information for CE</b> EMC specifications	EN 61000-6-2 EN 61000-6-3* EN 55032 (Class B)
<b>Information for USA</b> This equipment has been tested and found to comply with part 15 of the FCC Rules.	Class B
<b>Information for Canada</b> <b>Renseignements pour le Canada</b>	CAN ICES-3 (B)/NMB-3(B)
<b>Information for UL</b>	UL Listed UL 62368-1 CSA C22.2 No. 62368-1-14
<b>Information for UK</b> EMC specifications	UKCA EN 61000-6-2 EN 61000-6-3* EN 55032 (Class B)
<b>Further information</b>	RCM KC (R-R-img-USB31SE) ChinaRoHS EFUP 25

\* Cameras are intended for use in industrial, residential, commercial and light industrial environments.

### For customers in the USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and Receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Name of Responsible Party

IDS Imaging Development Systems Inc.  
92 Montvale Ave, Suite 4750  
02180 Stoneham, MA | U.S.A  
+1 781 787-0048

### 3.1.2 PCB version

IDS Imaging Development Systems GmbH hereby confirms that this product has been developed, designed and manufactured in compliance with the following European directives

- 2011/65/EU: RoHS - Restriction of the use of certain hazardous substances in electrical and electronic equipment
- Regulation (EC) No. 1907/2006 concerning the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH)

#### Further Information

- ChinaRoHS EFUP 25

## 3.2 Ambient conditions

The temperature values given below refer to the outer device temperature of the camera housing. The temperature inside of the camera housing is generally higher than the outer temperature and may be up to 70 °C (158 °F).

Allowed device temperature during operation	0 °C ... 55 °C 32 °F ... 131 °F
Allowed device temperature during storage	-20 °C ... 60 °C -4 °F ... 140 °F

Humidity	20 % ... 80 %, relative, non-condensing
----------	---

Non-condensing means that the relative air humidity must be below 100 %. Otherwise, moisture will form on the camera surface. If, for example, air has a relative humidity of 40 % at 35 °C (95 °F), the relative humidity will increase to over 100 % if the air cools down to 19.5 °C (67 °F); condensation begins to form.



**CAUTION!** As the camera housing may get hot depending on the operating conditions there may be risk of burns. Provide sufficient heat dissipation so that the housing temperature does not exceed 55 °C (131 °F).

#### Notes on ambient conditions

- Avoid high air humidity levels and rapid temperature changes when using IDS cameras.
- Temperatures below +4 °C (39 °F) combined with excessive relative air humidity levels can cause icing.
- Note that with increasing device temperatures, the image quality may decrease due to thermal noise, even if the camera is operated below the maximum specified temperature.

Provide sufficient heat dissipation to keep temperatures within the specified ranges. The exact temperature conditions depend on the mounting situation. In general, the following recommendations apply:

- Use a thermally-conductive surface, like a metal plate or a heat sink, for a passive heat dissipation.
- If necessary, provide an active cooling for example by means of a fan.

#### Vibration and shock resistance

Vibration and shock resistance of the cameras corresponds to EN 60068-2-6 and EN 60068-2-27.

## 3.3 System requirements

For operating the cameras, the following system requirements must be met:

- Interface: USB 3.0 port (Super Speed)
- CPU/Memory: The requirements regarding CPU/memory depend on the software used for image acquisition.

Depending on the sensor model, the camera performance may be limited with the minimum system requirements.

#### USB interface

For best performance and stability, all USB drivers and the firmware must be updated to the latest version. Current generation CPUs with energy saving technologies can cause bandwidth problems on the USB bus.

### 3.4 Connecting a uEye SE USB 3.1 Rev. 1.2



When you connect a new USB device with a PC or a new USB port for the first time, Windows update searches automatically online for a suitable driver. This may take some time depending on your system.

1. Install a USB3 Vision compliant software featuring a suitable USB driver e.g. [IDS peak](#).
2. Connect the camera to a USB3 port on the PC either directly or using USB hubs or repeaters. The camera will be recognized automatically. When the camera has been correctly installed, the camera LED lights green.

It is recommended to connect the cameras directly to the USB ports on the mainboard to get the maximum bandwidth.



When using a USB hub with external power supply the camera LED still may light green even if the data connection between the PC and the USB hub is interrupted after the camera driver was loaded completely.

#### Cables

Use USB compatible data cables that allow for USB Super Speed (5Gbit/s). Be aware of the maximum cable lengths for USB.

#### Notes on lens mounting

Mount only lenses that are suitable for the camera. Observe the information on the maximum immersion depth for lenses.

- Mount lenses in a dust-free environment.
- When removing the protection cap, hold the camera with the front facing downward to prevent dust or particles getting into the camera.
- Mount the lens while holding the camera with the front facing downward.
- Always store the camera and lens with the protection cap mounted.

For information on the immersion depth, see [Immersion depth for lenses](#).

## 4 Mechanical specifications

The mechanical data for each camera model can be found on our [website](#) directly at the respective camera model beneath in the "Downloads" tab.




Fig. 1: uEye SE USB 3.1 Rev. 1.2



**NOTICE!** Make sure to avoid mechanical or electrical damage of the printed circuit board or its connections. Do not touch the printed circuit board while it is powered. Always hold the board by the edges to avoid the risk of electrostatic discharge damage.



**NOTICE!** The camera connectors may be damaged if you install or remove the camera with plugged in cables. Therefore, first unplug the USB and/or I/O cable from the camera.




The applicable tolerances for the overall dimensions of PCBs are higher than the tolerances for housing dimensions.

## 5 Notes on PCB version

The specifications for maximum temperatures, mounting, shield and ESD protection are provided. The listed data is applicable for all uEye SE USB 3.1 Rev. 1.2 board level versions.

### Temperature information



**Fig. 2: Temperature information**

### Assembly information

The uEye SE USB 3.1 Rev. 1.2 board level version with front can either be assembled using the two holes on the underside of the front or using the four holes on the front panel. Attaching the front to the camera shield is only possible with the two options shown.




Fig. 3: Mounting via front (1)




Fig. 4: Mounting via front (2)

For versions without front, assembly is possible using two screws from the rear through the board level. Depending on the sensor, it is distinguished between models with S-board and L-board.

The following figure shows the assembly with S-board. The transport protection (two nuts and locking plate) must be removed first. The sensor board can then be separated from the board level and assembled. The board level is then re-fitted on the sensor board and screwed on.






Fig. 5: PCB version with S-board

The following figure shows the assembly with L-board.






Min. M2,5x30  
DIN7985 ISO7045  
Torque 0.7Nm

Fig. 6: PCB version with L-board

## ESD protection

- For optimum ESD protection, keep a clearance on all sides of 4 mm from unshielded housings. A smaller clearance is possible with shielded housings.
- The PCB should be mounted with the fixing screws on a base connected to the shield. If this is not possible, an insulating connection must be ensured.
- The connection cable should have a shield with low-resistance on both sides.



At least 4mm clearance between board outline and non-shielded housing.

For shielded housings less clearance is allowed.

Fig. 7: ESD protection

## 6 Optical specifications

### [Immersion depth for lenses](#)

### [Position accuracy of the sensor](#)

### 6.1 Immersion depth for lenses

Some C-mount lenses reach deep into the camera flange. This may cause the lens to push against the back of the filter glass inside the camera or even make it impossible to screw in the lens.

The table below indicates the maximum possible immersion depth. The actual immersion depth of a lens is given in the relevant data sheet. As lens parts with a small diameter are allowed to reach deeper into the camera flange, the immersion depths are specified based on the diameter (named as A, B, and C in the image below).

Beside the immersion depth also the back focal length has to be considered, that means the distance between the last lens and the sensor (named "bfl" in the image below). The back focal length can be calculated for C-mount/TFL-mount with the following formula:

$$bfl = 17,526 - x$$

x stands for the maximum immersion depth (see table below).




Fig. 8: Camera front (sectional view)



The data given in the table include the following tolerances as a safety clearance:

- Immersion depth: 0.2 mm
- Diameter: 0.2 mm

Type	Thread depth (min.)	For diameter at lens end [mm] Ø A	Resulting maximum immersion depth [mm]	Minimum required back focal length [mm]
C-mount	5 mm	24.0	11.0	6.5

## 6.2 Position accuracy of the sensor

The following illustrations show the tolerance margins of the sensor position relative to the outer camera front. A maximum error in all directions (rotation, translation) cannot occur at the same time.




Fig. 9: Position accuracy of the sensor (1)




Fig. 10: Position accuracy of the sensor (2)

It cannot be guaranteed that the sensor cover glass or filter glass are absolutely parallel to each other.



C-mount/TFL-mount lenses can also be subject to inaccuracies of the flange back distance. The tolerance usually is  $\pm 0.05$  mm. In some cases, however, the inaccuracies of camera and lens might add up, resulting in a total error  $> 0.05$  mm.

Position accuracy, in each direction	$\pm 0.3$ mm
Horizontal/vertical rotation ( $\alpha$ )	$\pm 1.0^\circ$
Translational rotation ( $\beta$ )	$\pm 1.0^\circ$
Flange back distance	$\pm 0.05$ mm

## 7 Electrical specifications

[Pin assignment I/O connector](#)

[Digital input wiring](#)

[Digital output wiring](#)

[General Purpose I/O wiring](#)

### 7.1 Pin assignment I/O connector



**NOTICE!** The General Purpose I/Os are not potential-free and have no protective circuit. Faulty wiring (overvoltage, undervoltage) can result in a damage in the electronics.

#### 8-pin Hirose connector (HR25-7TR-8PA(73))


Pin	Description	
1	Ground (GND)	
2	<a href="#">Flash output</a> , with optocoupler (-)	
3	<a href="#">General Purpose I/O</a> (GPIO) 1, 3.3 V	
4	<a href="#">Trigger input</a> , with optocoupler (-)	
5	<a href="#">Flash output</a> , with optocoupler (+)	
6	<a href="#">General Purpose I/O</a> (GPIO) 2, 3.3 V	
7	<a href="#">Trigger input</a> , with optocoupler (+)	
8	Voltage output <ul style="list-style-type: none"><li>Without USB Power Delivery: 5 V, max. 100 mA</li></ul>	

Fig. 11: Hirose connector male, camera rear view

The color assignment of the used I/O cable is specified in the data sheet of the cable. For I/O cables from IDS Imaging Development Systems GmbH, you can find the data sheet on the website. Select the specific I/O cable in the [download area](#) and view the associated data sheet.



The maximum length of the I/O cable is 30 m. The cable must be shielded.

#### Power supply

The camera is supplied with power via the USB 3.0 interface. Information on the power consumption of individual camera models can be found in the model data sheet.

## 7.2 Digital input wiring

	Symbol	Min.	Typ.	Max.	Unit
Input high range	$V_{IH}$	5	-	24	V
Input low range	$V_{IL}$	0	0	1	V
Input leakage current	$I_I$	-	-	-	$\mu A$
Trigger pulse width (edge)		10	-	-	$\mu s$
Trigger edge steepness		35	-	-	V/ms

For interpreting the trigger signal, either the rising or the falling edge can be used. The digital input is galvanically isolated using an optocoupler to protect the camera and the PC against surges. Only DC voltages may be applied to the digital input.

The signal source of the trigger must be able to carry a load of at least 20 mA.

### Digital input wiring




Fig. 12: Wiring of the digital input

### Absolute maximum rating

	Symbol	Max.	Unit
Voltage range	$V_{CC}$	30	V

## 7.3 Digital output wiring

	Symbol	Min.	Typ.	Max.	Unit
Recommended supply voltage	$V_{CC}$	-	-	30	V
Collector-emitter saturation voltage	$V_{CE(SAT)}$	0.03	-	0.15	V
Collector-emitter breakdown voltage	$V_{(BR)CE}$	50	-	-	V
Collector current continuous	$I_C$	-	-	150	mA

The digital output is galvanically isolated using an optocoupler to protect the camera and the PC against surges. Only DC voltages may be applied to the digital output.

The output of the optocoupler can be used as an open collector or open emitter output. This means that the output signal can be connected to ground or to the supply voltage. The output signal is active if the collector-emitter switch is closed.

Further information on flash configuration can be found in the IDS peak manual in the ["Flash configuration"](#) topic.

### Digital output wiring

The following figures show examples of how the digital output is wired.




Fig. 13: Wiring of the digital output as an open collector output




Fig. 14: Wiring of the digital output as an open emitter output

## 7.4 General Purpose I/O wiring


The two programmable GPIOs (general purpose I/O) can be used as inputs or outputs. This selection is made by software using the corresponding functions. Please observe the following criteria:

	Symbol	Min.	Typ.	Max.	Unit
IO voltage range	V <sub>CCIO</sub>	0	-	3.3	V
Input high range	V <sub>IH</sub>	2.0	-	3.3	V
Input low range	V <sub>IL</sub>	0	-	0.8	V
Output high range	V <sub>OH</sub>	3.2	-	3.3	V
Output low range	V <sub>OL</sub>	-	0	0.2	V
Output current high	I <sub>OH</sub>	-	-	4	mA
Output current low	I <sub>OL</sub>	-4	-	-	mA



**NOTICE!** The General Purpose I/Os are not potential-free and have no protective circuit. Faulty wiring (overvoltage, undervoltage) can result in a damage in the electronics.

## GPIO wiring as input





## Beschaltung des GPIO als Ausgang




Fig. 16: GPIO wiring as output (1)

Socket male –  
Camera view

1 GND  
3 GPIO 1  
6 GPIO 2




Fig. 17: GPIO wiring as output (2)

## 8 Operating the uEye SE USB 3.1 Rev. 1.2

The uEye SE USB 3.1 Rev. 1.2 cameras are Vision compliant models. All camera features are described in the [Camera feature reference](#) in the IDS peak user manual. An overview of the specific functions of your camera model can be found in the corresponding data sheet.

You can operate your uEye SE USB 3.1 Rev. 1.2 camera using the software development kit IDS peak. IDS peak contains all libraries and software tools required for operating and programming. With an easy to understand programming interface, it simplifies the use of GenICam without limiting or bypassing its functionality.

For the software and documentation for your camera go to <https://en.ids-imaging.com/downloads.html> and select your camera model.

For additional information on operating the camera, see the following sections:

[Status LED](#)

[Filter types](#)

### 8.1 Status LED




Fig. 18: Status LED

The camera has a two-color LED that indicates information on the current status.

Camera is off/no power	■	■	■	■	■	■	■	■
Camera is booting	■	■	■	■	■	■	■	■
Camera is ready/open	■	■	■	■	■	■	■	■
Camera is open (reduced speed at USB 2.0 port)	■	■	■	■	■	■	■	■
No firmware loaded	■	■	■	■	■	■	■	■
Service firmware is active	■	■	■	■	■	■	■	■
Service firmware: Configuration by host	■	■	■	■	■	■	■	■
Camera error: <a href="#">Contact support</a>	■	■	■	■	■	■	■	■

## 8.2 Filter types

Every camera has a filter glass in the front flange to prevent the entry of dust particles. Color cameras by default use an IR cut filter (type HQ), which is required to ensure correct color rendering. For monochrome cameras, the standard filter is a glass filter (type GL). The filter type is given at the end of the model name.

The following table shows an overview of the different optical filters used in IDS cameras:



Filter type	Name	Refractive index ( $n_{\text{Filter}}$ )	Glass type	Thickness (f)	Cut-on wavelength	Cut-off wavelength	Non-reflective
IR cut filter	HQ	1.53	D263	1 mm	-	650 ±10 nm	On one side
Glass	GL	1.53	D263T	1 mm	330 nm	-	On both sides
Daylight cut filter	DL	1.53	RG695	1 mm	695 nm	-	-


You can tell the filter type from the outside by its coloration:

- Reddish glass: HQ filter
- Plain glass: GL filter
- Dark glass: DL filter



All sensors have a cover glass. The transmission of the cover glass is taken into account in the camera data sheet.

**Infrared cut filter (type HQ)****Fig. 19: HQ filter****Plain glass filter (typ GL)****Fig. 20: Glass filter**

**Daylight cut filter (type DL)****Fig. 21: DL cut filter**

## 9 Maintenance

### [Cleaning the filter glasses](#)

### [Cleaning the sensor](#)

## 9.1 Cleaning the filter glasses

When handling the camera with its lens removed, the filter glass can get soiled from the outside. This might be visible in the images that are captured. The filter glass should therefore be cleaned in that case.



It is strongly recommended to return the cameras to IDS Imaging Development Systems GmbH for professional cleaning.

IDS Imaging Development Systems GmbH is not liable for any damage resulting from cleaning the filter glasses. This even applies if the following instructions have been observed.

### Instructions for cleaning filter glasses

- The filter glasses may only be cleaned from the outside. If you remove the glasses, the sensor might get soiled. IDS Imaging Development Systems GmbH is not liable for any damage to the sensor resulting from removal of the filter glasses.
- First, remove dirt particles on the glass using compressed air. Do not use compressed air from compressors or spray cans since it often contains oil droplets or droplets of other liquids. For best results, use purified nitrogen from nitrogen bottles.
- Only use lint-free wipes or cotton-free swabs for cleaning. Never touch the filter glasses with your bare fingers because often, fingerprints cannot be removed completely afterwards.
- We recommend to use pure alcohol for cleaning. 100% isopropyl alcohol evaporates without leaving any residues. Only add small quantities of alcohol to the wipe. Never pour alcohol directly onto the camera.



**NOTICE!** Never use cleaning agents containing acetone for cleaning the filter glasses!

Acetone may damage the filter glass coating and may deteriorate the optical quality of the glasses.

### Cleaning the filter glass

Use a soft wipe to wipe off dirt particles in a single sweep beyond the edge of the filter glass.



Fig. 22: Cleaning the filter glass  
(example)

## 9.2 Cleaning the sensor

### Prerequisites:

- All work must only be carried out by appropriately qualified personnel. Improper cleaning will void the warranty.
- Perform cleaning in a clean, dust-free environment.
- Pay attention to the ESD protection, as the camera can be damaged by static discharge (ESD).
  - Use antistatic gloves, clothing and materials. Wear antistatic straps for ESD protection and conductive shoes.
  - Place a conductive mat on the work table to prevent the generation of static electricity.
- For cleaning, use lint-free ESD-safe cloths that do not contain particles that could scratch the window and ESD-safe cotton-free cleaning swabs
- Use a compressed air product approved for optics

### Steps:

- Prepare the cleaning cloth:
  - Fold the cleaning cloth lengthwise several times until the flat area is no wider than the sensor.
  - Fold the cloth in half so that a cleaning swab can be placed inside.
  - Place a cleaning swab in the cloth.
- Blow off loose particles from sensor and camera with compressed air. We recommend using ionized air to be able to remove even statically charged particles.
  - Do not shake the compressed air tank during this process. Do not use compressed air from compressors.
  - Use only short, targeted blasts of air to prevent the camera from cooling down and causing condensation.
- Moisten the cleaning cloth with isopropyl alcohol.
- Clean the sensor with the cleaning cloth in an oriented cleaning direction with a single wiping motion.
- Check if the cleaning was successful. If necessary, repeat the cleaning process with a new cleaning cloth.



**- A -**

Ambient conditions 11

**- C -**

Camera

Housing 10

PCB 11

SDK 27

**- D -**

Daylight cut filter 28

Device temperature 11

Dimensions 14

**- E -**

EC directive 9

EMC immunity 9

ESD 6

**- F -**

FCC rules 9

Filter glass

clean 31

type 28

Flash 22

**- G -**

GPIO 23

**- H -**

Housing version 14

**- I -**

I/O connector 20

Immersion depth

lens 18

Immunity 9

Infrared cut filter 28

Input

digital 21

**- L -**

Linux 12

**- M -**

Maintenance 31

**- O -**

Operating system

Linux 12

Windows 12

Output

digital 22

**- P -**

Pin assignment 20

Plain glass filter 28

**- S -**

Safety 6

Sensor

clean 32

position accuracy 19

Specification

camera 9

electrical 20

optical 18

Status LED 27

System requirements 12

**- T -**

Trigger 21

**- U -**

uEye SE USB 3.1 Rev. 1.2

ESD protection 15

PCB version 15

USB

cable 13

Hub 13

Use

intended 6

**- W -**

Windows 12